




VQ1530SIWDC













27



. 16

22

28









| 19

TABLE OF CONTENTS

SECTION

PAGE

Symbols	6
Safety Information	7
Inpacking and Checking Carton Contents	
Assembly	10
Operation	
Naintenance	
Troubleshooting	
Technical Data	15
Recycling and Disposal	15

Thank you for purchasing this Vacmaster[®] wet and dry vacuum cleaner. Feel confident that with Vacmaster[®] you are obtaining a high-quality product that is engineered for optimal performance. This vacuum cleaner is suitable for use with both liquids and dry materials.

FOR YOUR SAFETY: CAREFULLY READ AND UNDERSTAND ALL INSTRUCTIONS.

SYMBOLS

Caution
Read operator's manual.
Vacuum cleaners of dust category L according to IEC/EN 60335-2- 69 for dry vacuuming of materials with an exposition limit value > 1 mg/m ³ that are hazardous to one's health.
WARNING: The vacuum cleaner may contain materials that are hazardous to one's health. Have the emptying and maintenance, incl. the disposal of dust-collection container, carried out by specialists. Appropriate protective equipment is required. Do not operate the vacuum cleaner without the complete filter system. Otherwise there is danger to your own health.

READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE USING THIS VACUUM CLEANER.

This machine is intended for commercial use, for example in hotels, schools, hospitals, factories, shops, offices and rental businesses.

When using the equipment, a few safety precautions must be observed to avoid injuries and damage. Please read the complete operating manual with due care. Keep this manual in a safe place so that the information is always available. If you give the equipment to any other person, give them these operating instructions as well. We cannot accept any liability for damage or accidents which arise due to a failure to follow these instructions and the safety information.

- Never leave the appliance switched on unattended, if you leave the work area, switch the appliance off or unplug it from the power supply.
- Do not vacuum or use this Wet and Dry Vacuum cleaner near flammable liquids, gases or explosive vapours like gasoline or other fuels, lighter fluids, cleaners, oil-based paints, natural gas, hydrogen, or explosive dusts like coal dust, magnesium dust, grain dust or gun power. Sparks inside the motor can ignite flammable vapours or dust.
- This vacuum cleaner is not suitable for the vacuuming of asbestos or asbestos dust.
- Do not vacuum anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Ensure the hose and connections are always pointed away from the users face, hair, ears and eyes during operation and never direct the nozzle towards persons or animals.
- Clear the working area of any items or precessions that you do not wish to be vacuumed before operation.
- Keep cord away from heated surfaces.
- Do not expose to rain. Store indoors.
- Do not unplug by pulling on the cord. To unplug, grasp the plug, not the cord.
- Do not use with damaged cord, plug or other parts.

- Do not pull or carry by cord, use cord as handle, close a door on cord, or pull cord around sharp edges or corners.
- Do not handle the plug or vacuum cleaner with wet hands.
- To reduce the risk of health hazards from vapours or dusts, do not vacuum toxic materials.
- Frequently check that the float valve positioned underneath the motor is able to move freely.
- Do not use or store near hazardous materials.
- Do not use this vacuum cleaner with a torn filter or without the filter installed.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- To reduce the risk of injury from accidental starting, unplug power cord before changing or cleaning filter.
- Do not leave vacuum cleaner unattended when plugged in. Unplug from power supply when not in use and before carrying out maintenance.
- Turn off Wet and Dry Vacuum cleaner before unplugging.
- Do not cover the ventilation openings. Do not vacuum with any ventilation openings blocked; keep free of dust, lint, hair or anything that may reduce air flow.
- Keep hair, loose clothing, fingers, all parts of body away from openings and moving parts.
- If the supply cord is damaged, it must be replaced by the manufacturer, a qualified service agent or similarly qualified persons in order to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge.
- Children should be supervised to ensure that they do not play with the appliance.
- Always unplug the appliance after use and before cleaning or changing the filters or accessories.
- Only use the socket outlet on the machine for purposes specified in the instructions.
- If foam or liquid escapes from the machine, switch off immediately.
- Clean the float valve regularly and examine it for signs of damage.

WARNING: When carrying out service or repair

operations, all contaminated items which cannot be satisfactorily cleaned are to be disposed of; such items shall be disposed of in impervious bags in accordance with any current regulation for the disposal of such waste.

When using as blower:

- · Direct air discharge only at work area.
- Do not use Wet/Dry Vacuum as a sprayer.
- · Do not direct air at bystanders.
- · Keep children away when blowing.
- Wear safety goggles.

UNPACKING AND CHECKING CARTON CONTENTS

Component List

- 1. Carry Handle
- 2. On/Off Switch
- 3. Latch
- 4. Rear Wheel
- 5. Front Caster
- 6. Drainage Port
- 7. Container
- 8. Suction Port
- 9. Power Take-off Socket
- 10. Power Head
- 11. Power Cable Hook
- 12. Accessory Storage
- 13. Blowing Port
- 14. Suction Hose
- 15. Power Tool Hose Adaptor

- 16. Extension Wand (x3)
- 17. Round Dust Brush
- 18. Foam Filter
- 19. Dust Bag
- 20. Crevice Tool
- 21. Hard Floor Nozzle
- 22. HEPA H13 Cartridge Filter (pre-installed)
- 23. Filter Retainer (pre-installed)
- 24. Pre-filter
- 25. Metal Accessory Adaptor
- 26. Washer (x4)
- 27. Hub Cap (x2)
- 28. Wheel Retaining Pin (x2)
- 29. Wheel Axle
- 30. Screw (x2)
- 31. Instruction Manual

ASSEMBLY

NOTE: A Phillips screwdriver is required.


- 1. Remove all the contents from inside of the vacuum cleaner container.
- 2. Attach the carry handle into the slots located on the top of the power head (Fig. 1).
- 3. Turn the container upside down and insert the front feet with casters into the slots and apply pressure until they click into place (Fig. 2).
- 4. Insert the wheel axle into the rear wheel housing on the base. Insert a washer onto the axle followed by the rear wheel and another washer. Insert the wheel retaining pin into the hole on the end of the axle to lock into place. Push fit the hub cap onto the wheel. Repeat the same steps on the other end of the axle (Fig. 3).
- Your vacuum cleaner comes ready for dry vacuum cleaning with the cartridge filter and pre-filter pre-installed. If the cartridge filter and pre-filter are not installed, refer to page 12.
- 6. Optionally, for improved dust filtration, fully fit the dust bag flange onto the inlet stub (Fig. 4).
- For wet vacuuming, replace the cartridge filter and pre-filter with the foam filter supplied. Do not use a dust bag when wet vacuuming. If the foam filter is not installed, refer to page 12.
- 8. Secure the power head back on the container, using the 2 side latches. Insert the locking end of the hose into the suction port of the container and turn clockwise to lock into place (Fig. 5).
- Choose the desired accessories and/or extension wands and push fit onto the hose nozzle. To
 use the dusting brush and crevice tool with an extension wand you will be required to use the
 metal accessory adaptor (Fig. 6).

OPERATION

1. Switching On/Off

Connect the mains plug to a suitable a power outlet.

Position	Status
I	on
0	off
11	automatic synchronized start-up



2. Power Tool Take-Off Operation (Fig. 7)

- 1) Connect the power cable of your power tool to the power take-off socket.
- If applicable, connect the vacuum suction hose to the dust extractor connector on your tool with the supplied adaptor.
- 3) Switch the vacuum cleaner to position II, as described in Switching ON/OFF. The moment you switch on the power tool, the vacuum cleaner will also switch on. Once the electrical appliance has been switched off, the vacuum cleaner switches off following a time lapse (around 5 second) to allow the suction tube to be emptied.

3. Dry & Wet Vacuum Operation

WARNING! ENSURE YOU READ, UNDERSTAND AND APPLY SECTION ENTITLED 'SAFETY INFORMATION'.

- 1) Verify that the correct filter is installed for wet or dry vacuuming and the container latches are secured.
- 2) Secure the locking end of the hose into the vacuum suction port.
- Push the desired accessories onto the hose nozzle. The air flow regulation allows you to change vacuum cleaner suction. For best cleaning results, fully close the air flow regulation (Fig. 8).
- 4) Plug the power cord into a power outlet.
- 5) Turn on the motor by assigning the switch to the "I" ON position.
- Once you have completed vacuuming, switch to the "O" OFF position and unplug the power cord from the power.

WARNING: ALWAYS CHECK THE MAXIMUM WATTAGE COMPATIBILITY OF THE POWER TOOL TAKE OFF SOCKET AGAINST THE DESIRED POWER TOOL BEFORE CONNECTING TO PREVENT OVERLOADING.

For Dry Vacuuming:

WARNING: BEFORE INSTALLING, REMOVING OR CLEANING THE VACUUM CLEANER FILTER, ENSURE THAT THE POWER CORD IS UNPLUGGED AND SWITCHED OFF.

- To prepare your vacuum cleaner for dry vacuuming, install the cartridge filter over the filter cage with the flat end of the filter towards the vacuum power head. Carefully push filter until it sits flush forming a tight seal.
- 2) Place the filter retainer cap on top of cartridge filter over the raised lip and tighten the retainer lock clockwise to secure against the internal filter cage (Fig. 9).
- Place the pre-filter on the collection tank. The pre-filter is designed to cover the full circumference of the tank. Replace the power head, and secure it in place (Fig. 10).
- 4) Optionally, fully fit the dust bag flange onto the inlet stub. The Vacuum cleaner can we be used with or without dust bags.

IMPORTANT: Check the filter regularly for optimal performance. An old or blocked filter will reduce suction performance.

For Wet Vacuuming:

- 1) To prepare your vacuum cleaner for wet vacuuming, remove the retainer cap and the dry use cartridge filter and pre-filter.
- Carefully install the supplied foam filter over the internal filter cage, making sure the whole cage is covered (Fig. 11).

WARNING:

DO NOT USE THE CARTRIDGE FILTER FOR WET VACUUMING. DO NOT USE A DUST COLLECTION BAG FOR WET VACUUMING. DO NOT USE THE PRE-FILTER FOR WET VACUUMING.

IMPORTANT! When vacuuming large quantities of liquids, do not immerse the nozzle completely; leave a gap at the tip of the nozzle to allow air inflow. The machine is fitted with a float valve that stops the suction action when the container reaches its maximum capacity. You will notice an increase in motor noise. When this happens, turn off the machine, disconnect from power supply, and drain the liquid. To continue vacuuming, replace the drainage cap.

4. Blower Operation

WARNING: KEEP BYSTANDERS CLEAR FROM BLOWING DEBRIS.

WARNING: WEAR A DUST MASK IF BLOWING CREATES DUST THAT MIGHT BE INHALED.

- 1) Make sure the container and any collected waste is emptied before using as a blower. This also includes removal of the dust bag.
- 2) Insert the locking end of the hose into the blowing port on the rear of the power head (Fig. 12).
- 3) Turn on the motor on by turning the switch to the 'I' ON position.



WARNING: REMOVE THE POWER CORD FROM THE POWER SUPPLY BEFORE CARRYING OUT ANY MAINTENANCE.

- 1) Keep all safety devices, air vents and the motor housing free of dirt and dust. Use a soft, dry brush to clean the equipment regularly.
- Clear all dirt or debris from the collection tank after each use. Allow to dry before replacing the power head. Do not use cleaning agents or solvents; these may damage the appliance.
- Check the hose, attachments, and power cord to verify that they have not been damaged or any debris is trapped and blocking airflow.

1. Cleaning Cartridge Filter & Pre-filter

Remove the filter and clean by gently tapping or brushing off dirt. For optimal performance it is recommended to replace the old filter with a new filter regularly.

2. Cleaning Foam Filter

Remove the foam filter and use a mild soap and water solution to wash and rinse with clean water (Fig. 13). Allow filter to air dry before installing and using again.

WARNING: TO REDUCE THE RISK OF ELECTRIC SHOCK-UNPLUG BEFORE TROUBLESHOOTING.

Cleaning Performance

Vacmaster vacuum cleaners are tested for endurance. If your motor is operating, then the most likely cause for a loss in suction is a blockage or an opening in the vacuum.

To maintain a high cleaning performance from your machine, it is important to replace or clean cartridge filters as necessary. Replace full dust bags to prevent performance drops. A performance drop with clean filters can only be caused by a blockage in the tools or the hose.

PROBLEM	POSSIBLE CAUSE	SOLUTION
The appliance does not work.	No power.	Check the power supply and fuse.
	Functional fault in the power cord, switch, or motor.	Have the damaged part checked by qualified personnel or contact the after sales helpline.
Dust is escaping from the motor cover.	The cartridge filter is missing or damaged.	Put in a cartridge filter or replace it.
	Misuse the cartridge filter when wet vacuuming, causing the damage of cartridge filter.	Replace the damaged cartridge filter with a new one when dry vacuuming.
	Misuse the foam filter when dry vacuuming.	Replace the foam filter with the cartridge filter.
Power tool take-off socket does not work.	Power tool wattage exceeds max power.	Check the wattage is compatible with the power tool take-off socket.
	Incorrect operating mode selected.	Ensure the switch is moved into position II.
Low suction power and high operating noise / vibrations.	Dust bag is full.	Replace the dust bag.
	Suction nozzle, hose, or tank inlet is blocked.	Check the suction nozzle, hose, and tank inlet for obstructions.
	Cartridge filter is blocked.	Remove the cartridge filter and clean.
	Float valve has closed.	Empty the container of any liquid waste and ensure the float value located underneath the filter is able to move freely.

TECHNICAL DATA

Model Number	VQ1530SIWDC
Motor	110V~50Hz
Power Input	1000W
Max. Power Consumption of the Power	760V
Tool Take-Off Socket Outlet	
Tank Volume	30L
Net Weight	8.3kg
Max. Vacuum Pressure	17.5kPa / 175hPa
Max. Flow Rate	38.9L/s / 140m³/h

Noise/Vibration Information

Noise emission values determined according to EN 60335-2-69.


Typically, the A-weighted sound pressure level of the power tool is <74.5 dB(A). Uncertainty K = 3 dB.

Total vibration values a_h (triax vector sum) and uncertainty K determined according to **EN 60335-2-69**: a_h <2.5 m/s², K =1.5 m/s².

RECYCLING AND DISPOSAL



This marking indicates that this product should not be disposed with other household wastes throughout the EU. The machine must be delivered in rigid packaging to avoid damage during transportation. The packaging and the machine itself are manufactured from recyclable materials and should be disposed of accordingly.



VQ1530SIWDC Suzhou Cleva Electric Appliance Co., Ltd. No.8 Ting Rong Street Suzhou Industrial Park, Suzhou Jiangsu Province, China www.cleva-europe.com Made in P.R.C