

- 1. Clean the surface and allow to dry.**
- 2. Cut draught excluder to required length.**
- 3. Peel off 100mm (4") of backing paper and press sticky side into position.**
- 4. Proceed, only removing short lengths of backing paper at a time.**

