



STORMGUARD GROUP

Regency Mill Chester Rd Macclesfield Cheshire SK11 8HR
Tel: 01625 613311/ 423085 Fax 01625 614434

BRUSH BOTTOM DOOR STRIP WITH PVC COVER CLIP FITTING INSTRUCTIONS

1. Measure bottom of door width.
2. Slide the brush out of the housing and cut the housing to size.
3. Using a pair of pliers cut brush to the same size ensuring the metal brush housing is crimped. This is to prevent the brushes falling out.
4. To prevent the brush insert coming out of the housing either crimp or glue at each end of the housing.
5. Screw firmly to base of door.
6. Adjust if necessary for perfect fit.
7. Hold the Clip Cover up to the door, mark it off to the same length as the metal housing and cut to size.
8. With the rubberised foot to the top, attach the Clip Cover to the brush housing as shown below. Pushing it firmly into position all along its length.

