

Installation guidance

Gyproc® EasiFill

Hand applied jointing for all stages

Step 1



Ensure that boards have been prepared for jointing

Step 2



Add approx. 6.5 litres of clean water per 10kg bag to a clean mixing bucket. Gradually add the powder stirring continuously until a smooth creamy consistency is achieved

Step 3



Apply Gyproc EasiFill to the joint to embed the joint tape at approximately 100mm width and immediately overcoat to fully fill the tapered board edges. Feather out onto the board surface

Step 4



Once fully dry and set, trowel apply a second coat and feather out to approx. 50mm beyond previous coat

Step 5



Apply a final coat if needed, feathering out another 50mm beyond the second coat

Step 6



Once all coats have fully dried, sand down to a smooth flat finish

Step 7



Seal the boards and joints with Gyproc Drywall Primer or Gyproc Drywall Sealer ready for decoration

Note:

Check Gyproc EasiFill variant packaging for working time and setting time information.

Gyproc EasiFill 20 is not recommended as a jointing product.

**Times and processes are given as guidance.
On site practice may vary.**