

### **Before starting work:**

1. Turn off any related heating appliance.
2. Isolate water supply to point of installation.
3. Drain system where necessary.

Some work is subject to regulations.

### **How to fit:**

1. Cut tube with a tube cutter to the desired length. Tube ends must be cut square and de-burred.
2. Remove compression nut and olive from the fitting.
3. Slip compression nut followed by olive onto tube.
4. Push tube fully into fitting.
5. Slide compression olive and nut onto the fitting and tighten by hand.
6. Whilst holding the fitting firmly tighten nut with spanner by 1-1 ¼ complete turns. Do not over tighten.
7. Turn on water and check all joints are watertight.
8. Turn on heating appliances.

If in doubt, contact a qualified plumber.