

Uses and limitations

For use on outlet hoses of nominal 19mm internal diameter.

This kit is not intended for use with a washing machine or dishwasher connected to an open-ended standpipe.

Installation instructions

1. Cut the outlet hose with a sharp knife at the highest point of installation.
2. Put a little PTFE tape on the male threads to give a good seal.
3. Insert anti-syphon device ensuring the arrows on the body line up with water flow and that the tabular relief valve is upright.
4. Ensure the outlet hose is pushed firmly into the anti-syphon device.

If in doubt contact a qualified plumber.