

## **Before starting work:**

1. Turn off any related heating appliance.
2. Isolate water supply to point of installation.
3. Drain system where necessary.

## **Compression – Instruction**

1. Cut tube with a tube cutter.
2. Slide nut and olive onto the tube and then onto the fitting and tighten by hand.
3. Hold fitting with spanner and tighten nut with another spanner by 1-1¼ turns (6-15mm), 1 turn (22mm), ¾ turn (28mm). Do not over tighten.
4. Turn on water and check for watertightness, further ¼ turn on nut where necessary.

If in doubt, contact a qualified plumber.