

Assembly Instructions Stainless Steel Single Cabinet

Parts Supplied

Ref	Description	Qty
A	SINGLE MIRROR CABINET	1

Tools Required(not supplied)

Cross Head Screwdriver Power Drill 6mm Masonry Drill Bit
--

Before fitting the cabinet

CAUTION:

Before drilling into any walls, check that there are no hidden cables or pipes. Exercise great caution when using power tools near water. We recommend the use of a Residual Current Device(RCD)

Please make sure the surface is suitable for installation of the cabinet and the fastening devices will withstand the forces generated by the loaded unit.

Do not fix to newly plastered or papered walls as chemical reactions can cause discolouration of the surface finish. When working near a basin or bath, insert the plug into the waste to avoid the possibility of losing any small parts.

Fitting the cabinet

Using a spirit level and the cabinet as a template, mark the drill holes in the required location. Always double-check the position and your measurements of the product before drilling the holes. MEASURE TWICE. DRILL ONCE!

WARNING: Wall fixings are not supplied with this pack as they will vary according to the type of walls you have. In order to prevent falling down please ensure you use the correct wall fixings for your wall type. If in doubt seek professional advice.

Cleaning

- Wipe clean with a soft damp cloth. Never use scourers, abrasives or chemical cleaners.