

# RAPID FLEX

# **FLEXIBLE RAPID SET** TILE ADHESIVE FOR **WALLS & FLOORS**

RAPID FLEXIBLE RAPID SET TILE ADHESIVE FOR **WALLS & FLOORS** Grev

**20**kg





Pot Life



Setting Time





External



Underfloor Heating



Bed **Thickness** 



Porcelain, Ceramic Natural Stone Mosaic

# **PRODUCT SELECTION GUIDE**

# **KEY AREAS OF USE:**

- **General wall installations**
- **General floor installations**
- Interior installations
- **Exterior installations**
- Wet rooms
- **Domestic showers with tray**
- **Communal showers**
- Swimming pools
- **Electric matting underfloor heating**
- Piped water underfloor heating
- Conservatories

# **SUITABLE TILES:**

- Ceramic **Porcelain**
- Glass
- Mosaics
- Marble
- **Travertine**
- Granite
- Limestone
- **Terracotta**
- **Ouarry**

- Slate

**Resin Backed** 

- Quartz
- × Brick Slips

# **SUITABLE SURFACES & SUBSTRATES:**

- Concrete Sand/cement screed
- Tile backer boards
- **Cement faced fibre boards**
- Anhydrite/calcium sulphate/gypsum based screeds
- Tile on Tile\*
- Firm and stable plaster
- **Plasterboard**
- Sand/cement render
- Concrete brick/block
- Hard vinyl tiles
- Flooring grade asphalt
  - \* Existing ceramic, porcelain and natural stone tiles (overlay) known as "Tile on Tile"

**UltraTrade Rapid Flex** is a single part, rapid setting, flexible, fibre reinforced adhesive for wall and floor tiles. It is specially formulated with Fibre Bond technology, enhanced adhesion and flexibility, making it ideal for areas where movement or vibration can occur. Classified as S2 in accordance with EN12004 it has the highest level of deformation for exceptional tolerance to movement. **UltraTrade Rapid Flex** contains a unique blend of polymers which provide a superior bonding performance in combination with an extended range of tile types in wet or dry conditions. It is able to take light foot traffic within 4 hours of installation depending upon temperature and substrate.

## **SURFACE PREPARATION**

All wall and floor substrates must be clean, dry, firm and stable, free of dust, dirt, oil and grease. Substrates should be strong enough to support the weight of the adhesive and tiles being fixed (see datasheet for loadings).

For plasterboard and plaster finishes that have been painted and are showing a weak or flaky surface finish then mechanical sanders or hand sanding blocks are generally used to remove the film. However for the likes of floor screed surface contamination, adhesive residues and weak surface laitance or even smooth dense floors such as power floated concrete, these will require a more heavy duty scarifying using specialist flooring equipment to remove the surface of the substrate to ensure the substrate is sound, stable and has a rough open texture. To encourage best adhesion to the substrate it is advisable that prior to applying adhesive that substrates are primed (please see priming section below).

Remember - sanding or mechanical abrasion of any surface will leave powder deposits which require thorough removal by suitable vacuum equipment to provide a clean dust free surface. Failing to remove fine powder deposits and weak surfaces is a common reason for de-bonding of tile adhesive and primer from the substrate. Using a wet sponge to clean down a wall or floor of dust deposits only serves to spread it around, it is therefore advisable to vacuum thoroughly prior to use of wet sponge.

**Wall Tiling:** Plywood and other wood-based sheets or boards should not be used for direct tiling. It is recommended in BS 5385-1 to use proprietary tile backer boards that provide a suitably rigid substrate to receive direct tiling.

**Tile on Tile:** It is always preferable to remove existing tiles however fixing new to old is an accepted method as long as the existing tiles are sound, stable, dry, securely bonded and fixed to a background that is capable of taking the additional weight. Ceramic, porcelain and quarry tiles should be lightly abraded to form a mechanical key degreased and ensured thoroughly clean. For existing vinyl floor tiles only hard and "crunchy" vinyl tiles should be considered to be over-tiled. Be aware that some old tiles of this type contained asbestos so should not be abraded. Do not over-tile onto softer vinyl, quartz or composite tiles.

**Calcium Sulphate Floor Screeds:** It is essential that the floor is fully dry, if in doubt always check the moisture level of the floor is below 75%RH using a hair hygrometer before continuing. This type of floor can also suffer from surface laitance issues creating a weak surface layer and therefore they are highly likely to require specialist mechanical abrasion as indicated above.

**Timber/Wooden Floors:** All chipboard and T&G flooring should be overboarded using exterior or class 3 type plywood boards or cement backer boards of suitable thickness to remove any deflection. All over-boarding should be dry and conditioned to the environment in which they are to be used. Plywood overboards should have backs and edges sealed to prevent ingress of moisture and atmospheric humidity. A neat coat of UltraTrade Primer should be used to carry out the sealing process prior to installing the boards. The plywood boards should then be positioned, close butted and firmly screwed (not nailed) through the underlying flooring to joists ensuring a max distance between fixings of 300mm centres or less. Plywood and other wood-based sheets or boards should not be used for direct tiling. For tiling onto plywood and other wood-based sheets or boards, an intermediate layer, such as an uncoupling membrane, reinforced tanking system or tile backer board should be used. If using cement backer board to over-board the timber/wood floor, then it should be of flooring grade and of suitable strength for the application to prevent deflection. It should be 6mm minimum thickness. The backer board should be bonded using a minimum classification of S1 type tile adhesive and the original wooden floor should be thoroughly cleaned and free of any surface coating or wood treatment. It should also be primed using a neat coat of UltraTrade Primer.

**Underfloor Heating (UFH):** If UFH is being installed it must be fully commissioned before starting the tiling process to ensure it is in full working order. This includes both electric mat and water pipe systems. Once the UFH has been commissioned it can be set to a low level to provide a max floor temperature of  $15^{\circ}\text{C}$  whilst the tiling and grouting processes are undertaken. It is critical that this temperature is not exceeded as this can force dry the adhesive and grout with the potential of causing cracks in the installation or tiles to de-bond. Maintain this temperature for a minimum period of 7 days while the installation cures and hardens. After this time the UFH can be brought up to the required room temperature slowly at a rate of  $5^{\circ}\text{C}$  per day.

**Render:** When tiling to new render it must be ensured that the render is a minimum of 4 weeks old and is thoroughly strong, dry, dust and efflorescence free and stable.

## PRIMING

Ultra Trade Primer has been specifically developed to be used as a primer for use with cementitious tile adhesives to provide improved sealing and bonding properties for a variety of substrates.

Porous Substrates (includes: plaster, skimmed plasterboard, plasterboard, sand/cement, calcium sulphate screeds, cement backer

boards, render and other open textured substrates): Prime with 2 coats of Ultra Trade Primer. The first coat should be diluted 1 part primer to 3 parts clean water (by volume) and allowed to dry for a minimum period of 1 hour. When dry, apply a second coat diluted 1:1 (by volume) and leave for 1 hour to dry before continuing the tiling process.

Non-porous & Low Porous Substrates (includes: cured epoxy DPMs, tile on tile applications, foil faced insulation boards, plywood floor overboarding, plywood walls): We recommend Ultra Trade Prime in a single, neat application.

NB: Please see technical datasheet for Ultra Trade Primer for coverage rate details. If in doubt as to the need for priming please consult UltraTrade Technical Department.

#### MIXING

Once the substrate has been prepared, continue with the tiling installation. **UltraTrade Rapid Flex** should be added slowly to clean water in a suitable clean mixing tub and mixed thoroughly using a drill/mixer and paddle to give a slump free, easily worked mortar consistency. Once mixed the mortar is immediately ready for use and has a pot life of approximately 60 minutes at 20°C. Mix only sufficient material to be used within the pot life of the product. Do not remix or rewet/dilute product which has aged and is starting to thicken or set.

Mixing Ratio: 20kg unit requires 4.0L of water.

#### APPLICATION

Apply the adhesive to the required thickness (limits 3mm - 20mm) in areas up to  $1m^2$  at a time. For internal walls use a notched trowel to the following notch dimensions to provide solid rib lines:

Mosaic tiles: 3mm x 3mm at 6mm centres
General wall tiles: 5mm x 5mm at 10mm centres
General floor tiles: 8mm x 8mm at 16 mm centres

For floors and external applications we advise to use the solid bed method. This involves applying a uniform bed of adhesive to the floor and "buttering" the back of the tile with the same adhesive. When the tiles are bedded with a twisting action, pressing firmly down it ensures 100% contact is made with both the floor and the tile.

When fitting tiles leave spaces between each of the tiles to allow for grouting (approx: walls 1 mm - 3 mm and floors 2 mm - 12 mm).

Before the tile adhesive sets clean off the excess adhesive from the face of the tile and grout joints with a clean damp cloth or sponge.

#### CLEANING

Tools should be thoroughly cleaned with water to remove excess material immediately after use and before adhesive sets.

#### GROUTING

Leave the installed tiles for a minimum period for at least 4 hours to set hard before grouting and/or walking on the tile. This time may be extended on impervious/non-porous substrates. It is also dependent on temperatures and conditions. Always check and ensure that adhesive has set hard before grouting.

## STORAGE

This product must be stored in unopened bags, clear of the ground in dry conditions. Avoid frost. Ideal storage temperatures are between  $5^{\circ}\text{C}$  and  $25^{\circ}\text{C}$ .

# SHELF LIFE

Under the above storage conditions this product has a shelf life of 12 months.

## **HEALTH & SAFETY**

Please ensure that appropriate PPE is used when preparing, mixing and applying products. Always wash hands before consuming food and make sure that materials are kept safely out of reach of children and animals. Please dispose of packaging and waste appropriately. A full Material Safety Data Sheet relating to this product is available from **myultratrade.com**.

## OUALITY ASSURANCE

All products are manufactured in a plant whose quality management system is certified as being in conformity with BS EN ISO 9001. Ultra Trade products are guaranteed against defective materials and manufacture and will be replaced or money refunded if the goods do not comply with our promotional literature. We cannot however accept responsibility arising from the application or use of our products because we have no direct or continuous control over where and how our products are used. All Ultra Trade products are sold subject to our terms and conditions of sales, copies of which may be obtained upon request.

Please note that this product uses natural aggregates and other materials that may marginally vary in colour. This does not affect the consistency or characteristics of the product.



Manufactured by
INSTARMAC

myultratrade.com
T: 01827 908555