



Step 1

Shake the bottle of SelectaDNA for 15 seconds before use.



Step 2

Choose an area to apply, ideally in crevices, textured surfaces or hard to reach areas. Ensure it is clean and dry.

NOTE: Electrical devices must be disconnected from the power supply. Do not apply to PCBs.



Step 3

Dip the applicator into the bottle, ensuring you have only a small amount of liquid, and ideally at least one microdot on the applicator.



Step 4

Apply the mixture to the item in a single thin layer. Although touch dry in approximately 30 minutes, the mark will take around one week to cure completely.

NOTE: Aim to mark larger items in more than one area.



Step 5

Apply a warning label to the marked items and warning stickers to ground floor windows and glass doors. This will act as a theft deterrent as thieves are scared of DNA.



Step 6

Register on the secure Home Office compliant and Police approved database so your property can be identified if lost or stolen.

www.secureassetregister.com



Step 7

After each use rinse the applicator under a tap so the foam tip remains soft for the next time you use the solution.



Official Police Security Initiative

