

Fixing Instructions

1. Open pack(s) and store flat in a pile for a minimum of 72 hours in the room in which they are going to be used. Shuffle the pile daily to ensure that all boards adapt to room conditions.
2. Fit Cladding battens around the perimeter of the area to be clad. Then fill in with further cladding battens spaced at maximum centres of 400mm and running at 90° to the cladding.
3. Fix each piece of the cladding to every cladding batten with either clips or panel pins.

IMPORTANT

- Traditional Cladding must be sealed immediately to avoid moisture absorption.
- Use wood varnish, wood stain or paint suitable for timber.
- Only fix with cladding clips or panel pins – Do not use adhesives.
- Do not fix in recently plastered rooms because of the high moisture content.
- Please ensure the ends are treated / sealed to prevent moisture ingress.