




www.kobledesigns.com

Malmo Lounge Furniture Set - 2 Seater



Care & Instruction Manual

Please read and retain these instructions for future reference

STOCK CODES : GFLMAL

Imported By: Koble Designs (Justwise Group Ltd). CB11 3AP.



Safety and Care Advice

Important – Please read these instructions fully before

Check you have all the components and tools listed on pages 3 and 4.

Remove all fittings from the plastic bags and separate them into their groups.

Small parts could choke if swallowed, keep children and animals away from work area.

Make sure you have enough space to layout the parts before starting.

Assemble the item as close to its final position (in the same room) as possible.

Assemble on a soft level surface to avoid damaging the unit or your floor.

Assembly requires 2 people.

Do not fully tighten bolts until the whole bed is assembled. Do not overtighten the nuts to avoid causing damage to the threads.



We do not recommend the use of power drill/drivers **for inserting screws,**

as this could damage the unit.
Only use hand screwdrivers and Allen keys.

Dispose of all packaging carefully and responsibly.

Place product on an even surface prior to using.

Suitable for Domestic Garden use only.

Children should not be left alone in situ with product, please refrain climbing onto the product.

Frequently check any damage to the product including the underside and tighten fixings where is required.

Cleaning Guidance

Daily cleaning:
Wipe clean with a damp cloth.
Use only clean water.
Wipe dry with a clean soft cloth.
Do not use detergents, solvents or other chemicals on oiled surfaces, as this may cause discoloration.
Color stains from eg. red wine or the like must be wiped off immediately.

For cushion covers, use sponge clean only.

We recommend the use of furniture covers when not in use.

In order to prolong the life of your product, we recommend it be stored in a dry and protected area during of season periods.
Do not use any abrasive substance which may scratch the surface.

Care and maintenance


From time to time check that there are no loose screws on this unit.

This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Do not stand on seating. Do not sit on arm or backrest ledges. Give your hardwood furniture a yearly scrub with soapy water, followed by a thorough rinse. This removes algae and pollution to restore the timber's surface, keeping it in good condition.

Main Components


Please check you have all the parts listed below




1 Seat frame Qty 1 (69x75x4.2cm)



2 Backrest frame Qty 1 (44x68x5cm)



3 Leg frame (left) Qty 1 (75x69x2cm)




4 Leg frame (right) Qty 1 (75x69x2cm)



5 Crossbar Qty 1 (2x2x131cm)



6 Seat Cushion Qty 1 (131x68x10cm)










7 Back Cushion Qty 2 (66x41x10cm)

For missing or damaged parts, call our **Customer Helpline: 01799 513466** or email cs@kobledesigns.com

Fixings, Fittings And Tools

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  40mm M8 Bolt Qty 4	B  M8 Washer Qty 4	C  35mm M6 Bolt Qty 4
D  20mm M6 Bolt Qty 4	E  M6 Washer Qty 6	F  Spanner K13 Qty 1
G  Allen Key Qty 1		


For missing or damaged parts, call our **Customer Helpline: 01799 513466** or email **cs@koble designs.com**




Assembly Steps

Step 1

Assemble backrest frame **2** to seat frame **1**, using fixings **C** and **E**.

Two people required



C 	E 	G 
35mm M6 Bolt Qty 2	M6 Washer Qty 2	allen Key Qty 1


Step 2







Assemble leg frames **3** and **4** to the seat frame, using fixings **A** and **B**.

Two people required

Secure the leg frames to the backrest, using fixings **D** and **E**.

Assemble crossbar **5** in between the leg frames, using fixings **C** and **E**.




A 	B 	C 	D 	E 	F 
40mm M8 Bolt Qty 4	M8 Washer Qty 4	35mm M6 Bolt Qty 2	20mm M6 Bolt Qty 2	M8 Washer Qty 4	Wrench key K13 Qty 1

Assembly Steps

Step 3

Further secure the backrest to the seat frame, using fixings **D** and **E**.



D



20mm M6 Bolt Qty 2

E



M6 Washer Qty 2


G



allen Key Qty 1

Step 4

Place seat cushion **6** and back cushions **7** on to the chair frame.



Assembly is complete.

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

WARNINGS

- Dispose of all packing carefully and responsibly.
Place product on an even surface prior to using.
Suitable for Domestic Garden use only .
Children should not be left alone in situ with product, please refrain children climbing onto the product.
Frequently check any damage to the product including the underside and tighten fixings where required.

Self Assembly

Check you have all the components and tools listed before assembly.
Remove all fittings from the plastic bags and separate them into their groups.
Keep children and animals away from the work area, small parts could choke if swallowed.
Make sure you have enough space to layout the parts before starting.
Do not stand or put weight on the parts during assembly, this could cause damage.
Assemble on a soft level surface to avoid damaging the unit or your floor.

Glass

This product is manufactured from toughened safety glass. In the unlikely event that the glass fails it will break into a large number of small fragments that may be spread over a wide area. This is a feature of toughened glass, designed to remove the risk of injury from glass breaking into large shards.
If the glass is chipped or broken, stop using the product.
Do not place very hot or very cold items on the glass.
Do not use the glass as chopping surface. Do not strike the glass with hard or pointed items.

Tables

Do not sit or stand on the table.

Chairs

Do not stand on the seating.

Sun loungers

Only one person to use lounger at any given time.
Ensure there are no persons sitting on lounger whilst adjusting back height.

Sofas

Do not sit on arm or back rest ledges.

CARE/CLEANING

We recommend the use of furniture covers when not in use.
In order to prolong the life of your product, we recommend it be stored in a dry and protected area during off-season periods.
Do not use any abrasive substances which may scratch the surface.

Glass

Wash glass with mild soap and water, rinse thoroughly, and dry glass completely.
Do not use any abrasive substances which may scratch the surface.

Timber

Give your hardwood furniture a yearly scrub with soapy water, followed by a thorough rinse. This removes algae and pollution on the timber's surface, keeping it in good condition.

Metal/Ratan

Use a clean soapy damp cloth and wipe down the surfaces – leave to fully dry before storing.
Do not use any abrasive substances which may scratch the surface.

Cushions

Sponge clean cushions only, For stubborn stains commercial available fabric cleaners are available please review application instructions on product before using on your cushions.

After Sales Support / Product Returns

In the unlikely event that you need to return the item because it is faulty, please follow the 'Product Returns' instructions at www.kobledesigns.com website.

Should you need to request replacement parts, please contact our after sales support team at:-

Email - CS@kobledesigns.com

Tel: +44 (0)1799 513 466

Address: Koble Designs, 6 The Shires, Shirehill industrial Estate, Saffron Walden, Essex, CB11 3AP

Purchased from other retailer

If you purchased your product from one of our retailer partners, please refer back to the retailer directly, for many customer services related issues, refunds or returns requests.

Koble designs may still be able to offer supports with technical related to queries.

Disposal



This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.