



Internal External letter sleeved box

1. Remove the old letter box from the door and ensure that the new letter box is the correct aperture of the opening
2. Slide the letterbox in each side of the door.
3. Using a screw driver, screw the letter box together.

TOOLS REQUIRED

Pencil, screwdriver,