

Uses and limitations

Only suitable for heating and plumbing applications using copper tube.

Suitable for hot and cold water services including mains.

Not suitable for gas.

Directions

1. Before starting work turn off any related heating appliance.
2. Isolate water supply at point of installation.
3. Drain system where necessary.
4. Cut copper tube with a tube cutter.
5. Clean tube and fitting, applying flux to both sparingly.
6. Push the tube firmly into the fitting and heat gently with a blow torch.
7. When flux boils and solder appears remove blow torch and allow joint to cool.
8. Wipe away all surplus flux.
9. Turn on water and check for leaks.

To protect paintwork and surroundings a flame mat should be used.

If in doubt, contact a qualified plumber.
