


### INSTALLATION


- Easy installation
- Fully adjustable




• Please follow these fixing and care instructions to ensure that your product is fitted safely and that it retains its high quality finish. Please retain this leaflet for future reference.

• **NOTE: The Universal Riser Rail Slider can be adjusted to fit rail dimensions between 18mm & 25mm.**


#### ① Unscrew riser to suit diameter of rail




#### ② Place onto rail



#### ③ Adjust height



#### ④ Tighten onto rail



### GENERAL CLEANING

• Do not use aggressive cleaning products or polishes or those which contain bleach, acids or alcohol as this may damage the surface of the product. Whilst modern plating techniques are used in the manufacture of these fittings, the plating will wear if not cleaned properly. The safest way to clean your product is to wipe with a soft damp cloth. Stains can be removed using washing up liquid.

**GUARANTEE TERMS:** In the unlikely event that this product does not meet your expectations or a quality issue arises, please contact your point of purchase with the details and your proof of purchase. We reserve the right to carry out a product inspection prior to validating a claim. The product carries a 1 year guarantee which covers against manufacturing defects. The guarantee does not cover deterioration through normal wear and tear, deterioration due to infestation, wilful damage, accident, improper or negligent use, unauthorised modification or repair, or incorrect storage. During the guarantee period for the product, we will, at our discretion, repair or replace the product, or the defective part, subject to the guarantee exclusions set out above and your claim being validated.