



Command water. At a touch

There are more exciting things to do than watching water boil. Let the SenseBoil® induction hob assist. It detects rising bubbles and automatically reduces to a low simmer. No more constant monitoring. So the focus can be on what matters most. Fine-tuning those flavours. Mastering that menu.

Product Benefits & Features



Boiling water, under control with the Boil Sensor

The Boil Sensor detects rising bubbles and automatically adjusts the temperature settings, reducing it to a controlled simmer. No more monitoring. Saving both time and energy.

- Hob type: Induction
- Hob with bevelled frame
- Direct Control: sliding touch control technology
- Controls position: Front Right
- Illuminated controls
- Digital indications for each zone
- Induction zones with power booster function
- Pot detection
- Left front zone: Induction, 2300/3200W/210mm
- Left rear zone: Induction, 2300/3200W/210mm
- Middle front zone: No, 0W/0mm
- Middle rear zone: No, 0W/0mm
- Right front zone: Induction, 1400/2500W/145mm
- Right rear zone: Induction, 1800/2800W/180mm
- Automatic fast heating up
- Key-lock function
- Child safety lock function
- Acoustic signal with switch off option
- Count up timer
- Eco Timer
- Timer function
- OptiHeat Control
- Easy installation thanks to snap-in system
- Main colour: Black



The hands-free hood

The Hob2Hood function connects the hob and the hood. The cooker hood automatically adjusts the fan speed based on the heat, without lifting a finger. For powerful extraction when searing. And quieter extraction when simmering.



Combine zones to cook more

This hob can easily cope when you're cooking large amounts – or simply with bigger pans. Just touch the Bridge button to link and control two cooking zones together to fit any large or long pan. Sharing the same temperature and time setting, the linked zones are ideal when you're cooking for dinner

Direct Access. Instant and effortless.

Enjoy effortless heat adjustments with Direct Access. Instead of tapping several times to increase the heat, you can now tap the number directly for the right amount of heat. Instantly.

The adaptable surface for every pan

The MaxiSense® self-sizing cooking zones detect the sizes and shapes of each pan. However large or small. It sends immediate heat to fit their bases, without compromising on performance. Experience the ultimate in kitchen adaptability. For complete culinary control.

Product Specification

Product Installation	Built_In	Built in height mm	44
Product Typology	Electric_Hob	Width cutting	560
Product Classification	Statement	Depth cutting	490
Installation	Independent	Radius cutting	5
Size	60	Fastening	Snap in System
Hob type	Induction Full	Gas original	No
Design family	AEG Vision	Gas replacement 2	No
Main colour	Black	Gas replacement 3	No
Control Panel material	Glass	Gas category	No
Frame type	Bevelled 4 Sides	Frequency	50-60
Frame material	No	Voltage	220-240V/400V2N
Knobs colour	No	Type of plug	No
Top Control Place	Front Right		
Type of controls	Kite 14 steps		
Control function	3 step residual heat, Acoustic signal, Automatic heating-up, Booster, Bridge function, Child-lock, Count up timer, Eco timer, Hob-hood connection, Key-lock function, Minute minder, SenseCook Boil, Sound off, Timer		
Other comments categorisation	Boil detect, Bridge ref. 949 597 577		
Width mm	590		
Depth mm	520		

