

EN User Manual | **Cooker Hood**

DBX3650M

DBX3651R

DBX3950M

DBX3951R

DBX4651M

DTX3640B

DTX3840B

DTX3840M



Welcome to AEG! Thank you for choosing our appliance.



In our drive to be sustainable, we are reducing paper assets and provide full user manuals online. Access your full user manual at aeg.com/manuals



Get usage advice, brochures, trouble shooter, service and repair information at aeg.com/support


1. SAFETY INFORMATION AND INSTALLATION

WARNING!

Refer to the separate Installation Instructions booklet for Safety Information and Installation. Read carefully the Safety chapters before any use or maintenance of the appliance.

2. PRODUCT DESCRIPTION

2.1 Control panel overview




-
- 1** **Lamp** - Turns the lights on and off.
 - 2** **First speed / Off** - The hood switches to first speed level. Second press turns off the appliance.
 - 3** **Second speed** - The hood switches to second speed level.
 - 4** **Third speed** - The hood switches to third speed level.
-


Care and cleaning

Removal of grease filter

Removal of charcoal filter - optional



Remove grease filter first.




1.


To install filters, perform steps in reverse order.

Clean the appliance and grease filters each month. Grease filters can be washed in a dishwasher. The time of saturation of the charcoal filter varies depending on the type of cooking and the regularity of cleaning the grease filter. Refer to leaflet included in the accessory.

This appliance is supplied with a LED lamp and separate control gear (LED driver). These parts can be replaced by a technician only. In case of any malfunction refer to "Service" in the "Safety Instructions" chapter.

3. ENVIRONMENTAL CONCERNS

Recycle materials with the symbol . Put the packaging in relevant containers to recycle it. Help protect the environment and human health by recycling waste of electrical and electronic appliances. Do not dispose of

appliances marked with the symbol  with the household waste. Return the product to your local recycling facility or contact your municipal office.

aeg.com

867382551-A-012024



UK
CA CE