

Fixing Instructions

1. When used internally open pack (s) and store flat in a pile for a minimum of 72 hours in the room in which they are going to be used. Shuffle the pile daily to ensure that all boards adapt to room conditions.
2. Fit Cladding battens around the perimeter of the area to be clad. Then fill in with further cladding battens spaced at maximum centres of 400mm and running at 90° to the cladding.
3. Fix each piece of the cladding to every cladding batten using suitable nails.

External use:

1. When this cladding is used externally it must be treated with an exterior timber preservative and either a high-performance exterior wood stain or exterior paint suitable for timber.
2. When used externally General-Purpose Cladding must be fixed to a timber framework made up of timber battens spaced at maximum centres of 450mm and running at 90° to the cladding.
3. When the cladding is fixed horizontally always ensure that the tongue is pointing upwards.
4. Fix each piece of cladding to every batten using two oval or lost head nails.

IMPORTANT

- When fixing the cladding either internally or externally use the appropriate type and number of nails – Do not use adhesives.
- General Purpose Cladding must be sealed immediately to avoid moisture absorption. Use wood varnish, wood stain or paint suitable for timber.
- Do not fix in recently plastered rooms because of the high moisture content.
- Always treat timber cladding when used externally.
- Please ensure the ends are treated / sealed to prevent moisture ingress.