




# Product Technical Sheet



## I. General

Product Description	Wickes Bending Spring - 15mm
SKU	500591
Brand	Wickes
Product image	<div>PRODUCT IMAGE</div> 



# Product Technical Sheet



## II. Reference data

<b>Specification</b>	<p>Wickes bending spring is for internal pipe bending. Simple and effective method for bending 15mm copper pipe.</p>
<b>Features and Benefits</b>	<ul style="list-style-type: none"><li>-Designed to maintain the internal dimension and prevent the pipework from cracking or collapsing;</li><li>-Manufactured from robust spring steel for longevity;</li><li>-Suitable for Copper Pipes;</li></ul>
<b>Application</b>	<ul style="list-style-type: none"><li>-Suitable for 15mm Copper Pipes;</li><li>-For internal pipe bending.</li></ul>


## III. Instructions & Note

### -Instructions-

#### STEP 1

Feed the tapered-end of the spring down into the pipe you wish to bend. Make sure you leave a small amount showing so that you can retrieve it again afterwards.

**Note:** If the pipe has been cut before, make sure to deburr the end of the pipe, or you may not be able to fit your spring into it. Only suitable for 15mm copper pipe.



#### STEPS

#### STEP 2

Locate the place at which you want your bend to be and place it against your knee. Gently pull back on the ends of the pipe until the desired angle is created. Retrieve your spring from inside the pipe.

**Note:** If you pull back too quickly or violently you risk creasing the pipe.

