




© 8x8 Sun Pent



Mass: 532.8 kg

**These instructions are for your safety. Please read through them thoroughly before use.
PLEASE KEEP THIS LEAFLET FOR FUTURE REFERENCE**

Let's get started...

Important information...



| | |
|--|-----------|
| Safety | 03 |
| Preparation of base | 04 |
| Warranty | 04 |
| Care, maintenance & Recycling | 05 |

In more detail...



| | |
|-----------------------------------|--------------|
| Parts List | 06 |
| Fascia & Nail List | 07 |
| Hardware chart | 08 |
| Before you start | 09 |
| Detailed Technical Drawing | 10-11 |
| Assembly instructions | 12-20 |

| | |
|-----|--|
| EN | For a copy of the instructions or a copy in another language please send an email or write to the address below. |
| F | Pour obtenir un exemplaire des instructions ou une copie dans une autre langue s'il vous plaît envoyez un e-mail ou écrire à l'adresse ci-dessous. |
| I | Per richiedere una copia del libretto di istruzioni, in italiano, o in un'altra lingua, per favore, invia una e-mail o scrivi a l'indirizzo sottostante. |
| PL | Na kopii instrukcji lub kopii w innym języku prosimy o wysłanie maila lub pisać na adres podany poniżej. |
| RUS | Для получения копии инструкции или копия на другом языке, пожалуйста, отправьте по электронной почте или написать по указанному ниже адресу. |
| TR | Başka bir dilde talimatları veya bir kopyasını bir kopyası için bir e-posta gönderebilir veya aşağıdaki adrese yazınız. |

Check that you have noted all the following instructions:



- ☒ We advise the use of non slip protective gloves throughout the assembly process.
- ☒ We advise the use of steel capped protective footwear throughout the assembly process.
- ☒ We advise that you use a helper to hold the glass in position whilst you nail the beading in place.
- ☒ We advise the use of protective headwear and safety goggles throughout the assembly process.
- ☒ Where a ladder is in use another person must hold the ladder.
- ☒ Do not attempt to work in windy conditions.
- ☒ We advise the use of a scaffold tower when fitting the roof, for felting or if you cannot reach from the ground.
- ☒ Do not allow children near the tools and work area.
- ☒ Follow any safety precautions quoted by the manufacturer for any equipment you use.
- ☒ Check all parts before assembly.
- ☒ Only use child and animal safe wood preservative.
- ☒ Do not use creosote.
- ☒ Allow the wood preservative to fully dry before use.
- ☒ Regularly check the building for wear and tear.



Important!



EVERY PRECAUTION IS TAKEN TO ENSURE THAT YOUR BUILDING HAS NO ELEMENT INCORRECTLY PLACED OR POSSIBLY HAZARDOUS, HOWEVER PRIOR TO USE PLEASE CHECK ALL SURFACES FOR THE FOLLOWING:

- (1) RAISED GRAIN, SPLINTERS: Sand down timber to smooth finish
- (2) NAIL/SCREW/PIN HEADS PROUD: Tap home to be flush with surface of timber
- (3) DAMAGED SCREW HEADS RESULTING IN SHARP SPLINTERS OF
- (4) METAL: Replace
- (5) SHARP ENDS OF NAILS/ SCREWS/ PINS PROTRUDING THROUGH THE PANEL: Remove and reposition
- (6) ENSURE ALL PARTS ARE SECURED AGAINST REASONABLE FORCE: Remove and refit
- (7) ENSURE THERE ARE NO LOOSE PARTS: Remove and refit/discard



IMPORTANT ! For your safety please read carefully the safety warnings

Preparation of base...

We recommend that the base onto which your building will stand should be at least 75mm larger in each direction than the total floor size of the building.

- **Actual floor area of the building:** 2444mm x 2390mm
- **Total height clearance:** 1965mm
- **Roof size:** 2580mm long x 2555mm deep

The chosen position in your garden for your building should be excavated to a depth of 75mm to allow a base of sand, on to which paving slabs can be evenly laid. You may also use an adjustable timber base or a concrete base. Whatever base you decide upon IT MUST BE LEVEL AND FIRM.

Warranty...

10 Year anti rot warranty subject to the following:

- The building must be raised so it is not in contact with any water retaining base surface (for example grass)
- This can be achieved using a timber, concrete or slab base
- When using a concrete or slab base use damp proofing strips under the bearers
- The building must have been completely treated and sealed immediately prior to or after assembly
- The building must have been re-treated and re-sealed annually

NOTE: Wood is a natural product, and therefore the following are excluded from the warranty:

- Colour change
- Warping
- Splitting.

The following are also excluded:

- Damage resulting from poor assembly
- Poor treatment application
- Poor care and maintenance
- Changes to the design
- Misuse
- General wear and tear.

Care, Maintenance and Recycling

The 5 golden rules of care:

- (1) Ensure your base is level and firm.
- (2) Ensure the building is not sitting directly on the ground using damp proof membrane or the optional timber base.
- (3) Ensure every piece of timber and surface, especially that is hidden upon assembly is treated with a top quality wood preservative at least twice (before assembly). Turn the panels upside down whilst painting so the treatment runs into the seams.
- (4) Garden buildings are not waterproof, therefore we recommend you seal between all the panels with a silicone based sealant.
- (5) Regularly check your roofing felt for weather damage and leaks.

The 6 golden rules of maintenance:

- (1) Visually check for weather damage.
- (2) Check and replace if necessary any Silicone sealant if used on your building.
- (3) Check the roofing material for wear.
- (4) The doors and windows may require periodical adjustment.
- (5) Ensure your building is well ventilated especially during hot weather.
- (6) During extremely hot periods humidify your building to prevent the timber from drying out.

Recycling and disposal:



packaging

1. Pallet and timber widely recycled
2. Cardboard widely recycled
3. Plastic strapping subject to local regulations
4. Plastic sheeting subject to local regulations.




Building


1. Timber widely recycled
2. Metal fixings widely recycled
3. Glass widely recycled
4. **Roofing felt not currently recycled.**

Stacked Parts List


Floor
(A1686)x02




Roof
(A1687)x01




Back
(A1689)x01




8' Window End LH
(A1690)x01




6' Door End
(A1691)x01




Front
(A1688)x01




Bench Leg
(A1692-1)x03



Bench Top
(A1692-2)x01




Felt Strips 2.7m
(A2555)x03



Glazing-Glass
(A2554)x14

Not to scale




Building Photographs


It will be greatly
appreciated if you could
forward images of your
completed
building to -
sales@shiregb.co.uk.

Fascia Bag Parts List


Side Fascia
(A2894)x02




Front Fascia
(A2556)x01




Front coverstrio
(A2575)x02




Rear Coverstrip
(A0016)x02



Beading 364mm
(A2461)x28



Beading 378mm
(A2462)x28



Vent
(A0476)x02



Black Knob Set
(A2888)x01




Hardware Chart

Scale 1:1


8mm Felt Nail
(A0023) x 152




16mm Panel Pin
(A0024) x 112




40mm Round head nail
(A0025) x 16



Black 25mm
Posi-drive screw
(A0031) x 04



60mm Posi-drive screw
(A0035) x 52



Before you start...



Things to check before you start:

- ☒ Ensure your base is ready – See page 4
- ☒ Check all parts as listed in the parts lists
- ☒ Read the instructions fully before starting work
- ☒ Follow all the health and safety guidelines.

When you see the drill icon

Only ever drill through the first piece of framework which will be a pilot hole for the screw to attach the second piece of framework

The required drill bit size is shown with the icon.



You will need:



• Hammer



• Spirit level



• Ladder



• 1mm 5mm drill bit



• Drill



• Tape measure & Ruler




• Sand paper



• Gloves



• Saw



• Pencil



• Goggles



• A helper for some tasks




• Screwdriver



• Sharp knife



• Masking tape



70x12x2545 fascia
A2894

coverstrip 1720mm
A0016

70x12x2574 fascia
A2556

8' 2390 LH Sun pent end
A1690

coverstrip 1900mm
A2575


360 x 373 glass
A2554

Beading 364mm
A2461

Beading 378mm
A2462

front panel
A1688

coverstrip 1900mm
A2575



In more detail.....



Assembly instructions:

These instructions are for your safety. Please read through them thoroughly before use.
Treat all the parts before assembly – see page 5!


GB-IE

Drill ONE of the **A1686 floor panels** only along the long piece of framework.
Push the two floor together and screw into place making sure they are flush and true to each other..
Turn the floors over and place on your base.





01



Floor panel
(A1686)x02



60mm Screws
(A0035)x04




GB-IE

Remove the transport blocks from the bottom of the panels by gently tapping one end with a hammer.
Drill the **A1690 end panel**, **Back panel A1689**, & **A1691 Door panel** as below.


Some of the holes are used later.

02



Inline with floor bearers

REMOVE
TRANSPORT
BLOCKS



Do not fix to the floor until asked



The **Back panel A1689** is positioned first on top of and is the same length as the **Floor A1686**. The cladding overlaps the floor. Push the **End panel A1690** up to the back panel.

Repeat with the **door panel A1691**.


Locate the Key and unlock the door.

The key is either screwed to the door framework or in the nail bag.


03




Back Panel
(A1689)x01








LH End Panel
(A1690)x01



Door End
(A1691) x01




60mm Screws
(A0035)x06




The **Front panel A1688** fits in front of the sides running the entire length of the floor.
The front panel only requires drilling ready to fix to the floor later
Again make sure the holes are inline with the floor bearers.





04



**Front Panel
(A1688)x01**



**60mm Screws
(A0035)x06**




REMOVE
TRANSPORT
BLOCKS

Unlock the door and fit the **Black Knob set A2888**.


05



**Black Knob set
(A2888)x02**




**25mm Black Screw
(A0031)x04**



1 Drill one 5mm hole all the way through the roof panel 17mm in from each end of the support frame.
Position the **Roof A1687** so the support frame sits on top of the ends frame and the slot goes over the cladding.
Centralise the roof and fix through the holes just drilled.
Mark a line level with the centre of the walls (about 84mm) drill through the roof only and fix with screws.


06







1



Roof Panel
(A1687) x01



60mm Screws
(A0035)x12





3 Strips of felt have been supplied. Fit the lowest strip first folding the felt over the roof edging, at the back then secure with a couple of nails at the top to hold the felt in position nail the sides to the wall with 4 nails each and at the bottom nail at approximately 100mm centres.


The middle piece overlaps the lower piece. Measure the roof and work out an even overhang.

Nail at approximately 100mm centres over the join then at the high edge and sides with 4 nails each to hold. Repeat with the last piece of felt




07



2.7m Felt strip
(A2555)x03




13mm Felt nails
(A0023) x152




GB-IE Fit cover strips at each corner and 4 nails each.


08




Front Cover strip
(A2575) x02



Back Cover strip
(A0016) x02





40mm Nails
(A0025)x16




GB-IE Fix the panels to the floor with 2x60mm screws per panel using the holes previously drilled.
NOTE make sure the screws go into the floor bearers.

09




60mmScrew
(A0035)x08




Fit the **side fascia's A2894** first so the front edge is flush with the felt at the corner.
 Drill and fix the Fascia's with 4 nails each side . Drilling prevents splitting.
 The **front fascia A2556** fits across the end fascia's. Drill and fix the Fascia with 5 nails .


10






Side Fascia
(A2894)x02



Front Fascia
(A2556)x01



40mm Nail
(A0025) x14



**GLASS HANDLE WITH CARE DANGER OF CUTTING
 USE GLOVES, SUITABLE SHOES AND CLOTHING.**





Swap the beading around to get the best fit. Fit with 2 panel pins each
 Get a helper to hold the glass whilst you fit the beading.

11




Glazing
(A2554) x14




Beading
(A2461) x28



Beading
(A2462) x28



16mm Panel pin
(A0024) x112



**WEAR CORRECT
 SAFETY EQUIPMENT!**





The **Bench Legs A1692-1** are fitted with the narrow side to the floor.


The outer pair are pushed up to the front and end walls drill 2 holes at the bottom and two at the top inline with the end framework.

The middle leg is fitted to the framework in the middle of the front panel with two screws.



12



Bench leg
(A1692-1) x03




60mm Screws
(A0035)x10




GB-IE

Drill 2 holes in each of the top face of the legs.
Position the **Bench top A1692** and screw into position.


13



**Bench Top
(A1692) x01**



**60mm Screws
(A0035)x06**




GB-IE

Push the **Safety vents A0476** into the holes in the back panel.–

14



**Safety vent
(A0476) x02**



20