



© 10x6 Sun Pent



These instructions are for your safety. Please read through them thoroughly before use.
PLEASE KEEP THIS LEAFLET FOR FUTURE REFERENCE

Let's get started...



Important information...

| | |
|--|-----------|
| Safety | 03 |
| Preparation of base | 04 |
| Warranty | 04 |
| Care, maintenance & Recycling | 05 |



In more detail...

| | |
|-----------------------------------|--------------|
| Parts List | 06 |
| Fascia & Nail List | 07 |
| Hardware chart | 08 |
| Before you start | 09 |
| Detailed Technical Drawing | 10-11 |
| Assembly instructions | 12-24 |

| | |
|-----|--|
| EN | For a copy of the instructions or a copy in another language please send an email or write to the address below. |
| F | Pour obtenir un exemplaire des instructions ou une copie dans une autre langue s'il vous plaît envoyez un e-mail ou écrire à l'adresse ci-dessous. |
| I | Per richiedere una copia del libretto di istruzioni, in italiano, o in un'altra lingua, per favore, invia una e-mail o scrivi a l'indirizzo sottostante. |
| PL | Na kopii instrukcji lub kopii w innym języku prosimy o wysłanie maila lub pisać na adres podany poniżej. |
| RUS | Для получения копии инструкции или копия на другом языке, пожалуйста, отправьте по электронной почте или написать по указанному ниже адресу. |
| TR | Başka bir dilde talimatları veya bir kopyasını bir kopyası için bir e-posta gönderebilir veya aşağıdaki adrese yazınız. |

Safety

Check that you have noted all the following instructions:



- We advise the use of non slip protective gloves throughout the assembly process.
- We advise the use of steel capped protective footwear throughout the assembly process.
- We advise that you use a helper to hold the glass in position whilst you nail the beading in place.
- We advise the use of protective headwear and safety goggles throughout the assembly process.
- Where a ladder is in use another person must hold the ladder.
- Do not attempt to work in windy conditions.
- We advise the use of a scaffold tower when fitting the roof, for felting or if you cannot reach from the ground.
- Do not allow children near the tools and work area.
- Follow any safety precautions quoted by the manufacturer for any equipment you use.
- Check all parts before assembly.
- Only use child and animal safe wood preservative.
- Do not use creosote.
- Allow the wood preservative to fully dry before use.
- Regularly check the building for wear and tear.



Important!

EVERY PRECAUTION IS TAKEN TO ENSURE THAT YOUR BUILDING HAS NO ELEMENT INCORRECTLY PLACED OR POSSIBLY HAZARDOUS, HOWEVER PRIOR TO USE PLEASE CHECK ALL SURFACES FOR THE FOLLOWING:

- (1) RAISED GRAIN, SPLINTERS: Sand down timber to smooth finish
- (2) NAIL/SCREW/PIN HEADS PROUD: Tap home to be flush with surface of timber
- (3) DAMAGED SCREW HEADS RESULTING IN SHARP SPLINTERS OF
- (4) METAL: Replace
- (5) SHARP ENDS OF NAILS/ SCREWS/ PINS PROTRUDING THROUGH THE PANEL: Remove and reposition
- (6) ENSURE ALL PARTS ARE SECURED AGAINST REASONABLE FORCE: Remove and refit
- (7) ENSURE THERE ARE NO LOOSE PARTS: Remove and refit/discard



IMPORTANT ! For your safety please read carefully the safety warnings

Preparation of base...

We recommend that the base onto which your building will stand should be at least 75mm larger in each direction than the total floor size of the building.

- **Actual floor area of the building:** 3040mm x 1790mm
- **Total height clearance:** 2118mm
- **Roof size:** 3220mm long x 1940mm deep

The chosen position in your garden for your building should be excavated to a depth of 75mm to allow a base of sand, on to which paving slabs can be evenly laid. You may also use an adjustable timber base or a concrete base. Whatever base you decide upon IT MUST BE LEVEL AND FIRM.

Warranty...

10 Year anti rot warranty subject to the following:

- The building must be raised so it is not in contact with any water retaining base surface (for example grass)
- This can be achieved using a timber, concrete or slab base
- When using a concrete or slab base use damp proofing strips under the bearers
- The building must have been completely treated and sealed immediately prior to or after assembly
- The building must have been re-treated and re-sealed annually

NOTE: Wood is a natural product, and therefore the following are excluded from the warranty:

- Colour change
- Warping
- Splitting.

The following are also excluded:

- Damage resulting from poor assembly
- Poor treatment application
- Poor care and maintenance
- Changes to the design
- Misuse
- General wear and tear.

Care, Maintenance and Recycling

The 5 golden rules of care:

- (1) Ensure your base is level and firm.
- (2) Ensure the building is not sitting directly on the ground using damp proof membrane or the optional timber base.
- (3) Ensure every piece of timber and surface, especially that is hidden upon assembly is treated with a top quality wood preservative at least twice (before assembly). Turn the panels upside down whilst painting so the treatment runs into the seams.
- (4) Garden buildings are not waterproof, therefore we recommend you seal between all the panels with a silicone based sealant.
- (5) Regularly check your roofing felt for weather damage and leaks.

The 6 golden rules of maintenance:

- (1) Visually check for weather damage.
- (2) Check and replace if necessary any Silicone sealant if used on your building.
- (3) Check the roofing material for wear.
- (4) The doors and windows may require periodical adjustment.
- (5) Ensure your building is well ventilated especially during hot weather.
- (6) During extremely hot periods humidify your building to prevent the timber from drying out.

Recycling and disposal:



packaging

1. Pallet and timber widely recycled
2. Cardboard widely recycled
3. Plastic strapping subject to local regulations
4. Plastic sheeting subject to local regulations.



Building

1. Timber widely recycled
2. Metal fixings widely recycled
3. Glass widely recycled
4. **Roofing felt not currently recycled.**

Stacked Parts List


| | | |
|---|---|--|
| <p>Floor (A1512)x02</p> | <p>Roof (A1517)x02</p> | <p>Back (A1766)x01</p> |
| <p>6' Window End LH (A1513)x01</p> | <p>6' Door End RH (A1516)x01</p> | <p>Front (A1765)x01</p> |
| <p>Bench Leg (A1772-1)x06</p> <p>scale 1:40</p> | <p>Bench Top (A1772-2)x02</p> <p>scale 1:40</p> | <p>Double Truss Bar (A3263)x01</p> <p>scale 1:70</p> |
| <p>06</p> | <p>Glazing-Glass (A2554)x16</p> <p>Not to scale</p> | <p>Felt Strips 3.3m (A1930)x03</p> |

Fascia Bag Parts List

Vent
(A0476)x02




Final
(A2178)x01




Black Knob Set
(A2888)x01




Side Fascia
(A3270)x02




Front Fascia
(A2915)x02




Front Cnr Coverstrip
(A2914)x02




Rear Coverstrip
(A2911)x01




Rear cnr Coverstrip
(A2912)x02




Front ctr coverstrip
(A2913)x01



Beading 377mm
(A0021)x32



Beading 364mm
(A3147)x32




Hardware Chart Scale 1:1


8mm Felt Nail
(A0023) x 140




16mm Panel Pin
(A0024) x128




40mm Round head nail
(A0025) x 42




Black 25mm
Posi-drive screw
(A0031) x04



60mm Posi-drive screw
(A0035) x81




80mm Posi-drive screw
(A0036) x12



Before you start...


Things to check before you start:

- ✓ Ensure your base is ready – See page 4
- ✓ Check all parts as listed in the parts lists
- ✓ Read the instructions fully before starting work
- ✓ Follow all the health and safety guidelines.


















6mm


When you see the drill icon
 Only ever drill through the first piece of framework which will be a pilot hole for the screw to attach the second piece of framework
The required drill bit size is shown with the icon.




You will need:

- | | |
|--|---|
|  <ul style="list-style-type: none"> • Hammer |  <ul style="list-style-type: none"> • Gloves |
|  <ul style="list-style-type: none"> • Spirit level |  <ul style="list-style-type: none"> • Saw |
|  <ul style="list-style-type: none"> • Ladder |  <ul style="list-style-type: none"> • Pencil |
|  <ul style="list-style-type: none"> • 1mm 5mm ,8mm,drill bit |  <ul style="list-style-type: none"> • Goggles |
|  <ul style="list-style-type: none"> • Drill |  <ul style="list-style-type: none"> • A helper for some tasks |
|  <ul style="list-style-type: none"> • Tape measure & Ruler |  <ul style="list-style-type: none"> • Screwdriver |
|  <ul style="list-style-type: none"> • Sand paper |  <ul style="list-style-type: none"> • Sharp knife |
| |  <ul style="list-style-type: none"> • Masking tape |

In more detail.....








In more detail.....

Assembly instructions:


These instructions are for your safety. Please read through them thoroughly before use.
Treat all the parts before assembly – see page 5!

GB-IE Drill ONE of the **A1512 floor panels** only at the corner of the framework at the closed end.
Push the two floor together and screw into place making sure they are flush and true to each other.





01



Floor panel
(A1512)x02





60mm Screws
(A0035)x02




GB-IE Remove the transport blocks from the bottom of the panels by gently tapping one end with a hammer.

02





REMOVE TRANSPORT
BLOCKS




Drill 6 holes in the LH End panel A1513 only
 The LH Back panel A1766 is positioned first on top of the Floor A1512 and goes into the corner. Notch to the middle of the back.
 The cladding overlaps the floor.
 Push the LH End panel A1766 up to the back panel. Do not fix to the floor until asked


03








LH Back Panel (A1766)x01



LH End Panel (A1513)x01



60mm Screws (A0035)x03






Building Photographs


It will be greatly appreciated if you could forward images of your completed building to - sales@shiregb.co.uk.

Drill 3 holes in the **LH Back panel A1766** only
 The **RH Back panel A1766** is pushed up to the other back panel and fixed together,
 Both the back and front panels fill the entire floor length.




04



**RH Back Panel
 (A1766)x01**




**60mm Screws
 (A0035)x03**




GB-IE

Drill 6 holes in the **RH End panel A1516** only
Drill 3 holes in the **LH Front Panel A1765** in the side where the notch is only.
Push the **RH End panel A516** up to the back and fix as before.
The **RH Front Panel A1765** goes in front of the side and screws from that panel.


05






LH Front Panel
(A1765)x01



Door End RH
(A1516)x01






60mm Screws
(A0035)x06




GB-IE

The remaining **Front panel A1765** fits in front of the side.
The front panel is fixed using the holes drilled in the last step.



06



Front Panel
(A1765)x01



60mm Screws
(A0035)x06




GB-IE

Unlock the door and fit the **Black Knob set A2888**.


07



Black Knob set
(A2888)x02



25mm Black Screw
(A0031)x04



GB-IE




The truss blocks are fitted with the slope towards the back.

The front block is fitted **44mm** below the notch and the back one **39mm**.


Drill a hole half way in to the blocks 8mm then through with a 5mm drill. And fix with 80mm screws.

Place the truss bars on the top and drill and counter bore as with the blocks and screw into position.




08



Double Truss bar
(A3263)x01




80mmScrew
(A0036) x12




GB-IE

1 Drill one 5mm hole all the way through the roof panel 17mm in from each end of the support frame.
Position the **Roof A1517** so the support frame sits on top of the ends frame and the slot goes over the cladding.
Centralise the roof and fix through the holes just drilled.
Mark a line level with the centre of the walls (about 100mm) drill through the roof only and fix with screws.


09







1



Roof Panel
(A1517) x01






60mm Screws
(A0035)x10




GB-IE Drill and fix the second roof panel as with the previous step.
Inside the building, where the roofs meet drill through one sides framework and fix together with 3 screws.


10



Roof Panel
(A1517) x01





60mm Screws
(A0035)x13




3 Strips of felt have been supplied. Fit the lowest strip first folding the felt over the roof edging, at the back then secure with a couple of nails at the top to hold the felt in position nail the sides to the wall with 4 nails each and at the bottom nail at approximately 100mm centres. The next piece overlaps the lower piece. Measure the roof and work out an even overhang. Nail at approximately 100mm centres over the join then at the high edge and sides with 4 nails each to hold. Repeat with the other piece of felt





11



3.3m Felt strip
(A1930)x03





13mm Felt nails
(A0023) x140




GB-IE Fit cover strips at each corner and 4 nails each.


12




Front cnr Cover strip (A2914) x02




Front ctr Cover strip (A2913) x01




Rear cnr Cover strip (A2912) x02



Rear Cover strip (A2911) x01





40mm Nails (A0025)x24




GB-IE Fix the panels to the floor with 2x60mm screws per panel using the holes previously drilled. **NOTE** make sure the screws go into the floor bearers.

13




60mmScrew (A0035)x12




GB-IE

Fit the **side fascia's A2916** first so the front edge is flush with the felt at the corner.
Drill and fix the Fascia's with 4 nails each side . Drilling prevents splitting.
The two **front fascia A2915** fits across the end fascia's. Drill and fix the Fascia with 3 nails each.
The **Final A2178** fits over the join in the middle of the front fascia. Drill and fix with 2 nails.

14




Side Fascia (A2916)x02





Front Fascia (A2915)x02



Final (A2178)x01



40mm Nail (A0025) x18



GB-IE



**GLASS HANDLE WITH CARE DANGER OF CUTTING
USE GLOVES, SUITABLE SHOES AND CLOTHING.**




Swap the beading around to get the best fit. Fit with 2 panel pins each
Get a helper to hold the glass whilst you fit the beading.


15




Glazing (A2554) x16






Beading (A3147) x32



Beading (A0021) x32



16mm Panel pin (A0024) x128



22






**WEAR CORRECT
SAFETY EQUIPMENT!**




GB-IE

The **Bench Legs A1772-1** are fitted with the narrow side to the floor.
The outer pair are pushed up to the front and end walls drill 2 holes at the bottom (into floor bearers) and two at the top inline with the end framework.
The middle legs are fitted at the framework in the middle of the front panels with two screws into the floor.




16



**Bench leg
(A1772-1) x06**







**60mm Screws
(A0035)x14**




GB-IE Position the **Bench top A1772-2** and screw into position with the holes drilled in the last step.


17



**Bench Top
(A1772-2) x02**



**60mm Screws
(A0035)x12**




GB-IE Push the **Safety vents A0476** into the holes in the back panel.

18



**Safety vent
(A0476) x02**



24