



# **Drybase® Plaster Membrane LP**

## **Product Description**

**Drybase® Plaster Membrane LP** is a low-profile plaster membrane for covering damp and salt-contaminated walls. The welded mesh allows for a plaster finish or "dot and dab" plasterboard system to be applied on top.

**Drybase® Plaster Membrane LP** is intended for use in above-ground situations.

#### **Benefits**

- Tough and pliable polypropylene
- · Minimal disturbance and preparation to existing substrate
- · Easy to cut with a knife or scissors

## **Properties**

Membrane material	Polypropylene
Sheet thickness	nominal 0.50 mm
Stud height	Approx. 2.0 mm
Unit weight	0.505 kg/m²
Working temperature	Max. +60 °C
Water vapour resistance	250 M equivalent air layer
Colour	Clear/Translucent, Mesh – white
Storage	Rolls to be stored upright and under cover if possible

### **Application Information**

**Drybase® Plaster Membrane LP** is suitable for damp-proofing only.

Remove loose and soft plaster/render, wallpapers and embedded timbers. Dub out voids, hollows and loose areas of masonry using a cement mortar.

Offer up the membrane and fix in place using sealed Plaster Plugs (use Drybase® Butyl Rope or moulded Plaster Plug Seals). Pull the membrane as tightly as possible against the structure to minimise hollow areas behind as these can interfere with the application of plaster or plasterboard. Fit the membrane tightly into and around corners, again to avoid



damage when applying finishes. Use a minimum of 13 fixings per square metre, spaced out in a regular 'diamond' pattern. In some cases, additional or alternative fixings, such as 'cob' plugs, may be required. Adjacent pieces of **Drybase® Plaster Membrane LP** are butted together (an overlap is not necessary), and sealed with Drybase® Overtape.

#### **Finishes**

**Plaster:** Tarmac Whitewall high impact plaster is typically applied as a suitable wet applied finish. A minimum of two coats should be applied. The initial 'scratch' coat should be well worked into the mesh facing, the minimum thickness should be 6 mm. Allow to cure for 7 – 10 days before applying subsequent coats. Do not allow the plaster or render to dry out too quickly or cracking may occur. Apply no more than a total of 15 mm of plaster.

**Plasterboard:** can be bonded using regular 'dab' adhesive or low expansion polyurethane foam adhesive. Apply the adhesive over the heads of the fixing plugs and ensure that 50 % of the membrane area is also covered. This ensures that direct 'through' contact is made between the plasterboard and the masonry substrate. Plasterboard fixed in this way can be skimmed the next day and painted or wallpapered a few days after that. Drying times are very much reduced when compared to 'wet' systems.

#### **Roll Sizes**

Rolls of:

 $1.0 \text{ m} \times 10 \text{ m}^2$ 

 $1.0 \text{ m} \times 20 \text{ m}^2$ 

 $2.0 \text{ m} \times 20 \text{ m}^2$ 

Technical Datasheet Last modified 04/22



#### **BUILT TO PROTECT**



### **Other Information**

For health and safety information see the Safety Datasheet (available upon request).

**Drybase® Plaster Membrane LP** is produced in accordance with ISO 9001 and ISO 14001 quality and environmental management systems.

Information given is in good faith based on experience and usage, however all recommendations are made without warranty or guarantee, since the conditions of use are beyond our control. All goods are sold in accordance with our Conditions of Sale, copies of which are available on request. Customers are advised that products, techniques and codes of practice are under constant review and changes occur without notice; please ensure you have the latest updated information.

Technical Datasheet Last modified 04/22 2 / 2

© 2022 Safeguard Europe Ltd., Redkiln Close, Horsham, West Sussex, RH13 5QL. T: +44 (0) 1403 210204 F: +44 (0) 1403 217529 E: info@safeguardeurope.com

......

www.safeguardeurope.com