


© Shire Arbour Foxglove



Let's get started...



Important information...

Safety	03
Preparation of base	04
Warranty	04
Care, maintenance & Recycling	05

In more detail...



Parts List	06
Hardware chart	07
Detailed Technical Drawing	08-09
Before you start	10
Assembly instructions	11-20

EN	For a copy of the instructions or a copy in another language please send an email or write to the address below.
F	Pour obtenir un exemplaire des instructions ou une copie dans une autre langue s'il vous plaît envoyez un e-mail ou écrire à l'adresse ci-dessous.
I	Per richiedere una copia del libretto di istruzioni, in italiano, o in un'altra lingua, per favore, invia una e-mail o scrivi a l'indirizzo sottostante.
PL	Na kopii instrukcji lub kopii w innym języku prosimy o wysłanie maila lub pisać na adres podany poniżej.
RUS	Для получения копии инструкции или копия на другом языке, пожалуйста, отправьте по электронной почте или написать по указанному ниже адресу.
TR	Başka bir dilde talimatları veya bir kopyasını bir kopyası için bir e-posta gönderebilir veya aşağıdaki adrese yazınız.



customerservice@shiregb.co.uk

Brigstock Road Wisbech Cambridgeshire PE13 3JJ
Tel 01945 465 295

Safety

Check that you have noted all the following instructions:



- We advise the use of non slip protective gloves throughout the assembly process.
- We advise the use of steel capped protective footwear throughout the assembly process.
- We advise that you use a helper to hold the glass in position whilst you nail the beading in place.
- We advise the use of protective headwear and safety goggles throughout the assembly process.
- Where a ladder is in use another person must hold the ladder.
- Do not attempt to work in windy conditions.
- We advise the use of a scaffold tower when fitting the roof, for felting or if you cannot reach from the ground.
- Do not allow children near the tools and work area.
- Follow any safety precautions quoted by the manufacturer for any equipment you use.
- Check all parts before assembly.
- Only use child and animal safe wood preservative.
- Do not use creosote.
- Allow the wood preservative to fully dry before use.
- Regularly check the building for wear and tear.

Important!

EVERY PRECAUTION IS TAKEN TO ENSURE THAT YOUR BUILDING HAS NO ELEMENT INCORRECTLY PLACED OR POSSIBLY HAZARDOUS, HOWEVER PRIOR TO USE PLEASE CHECK ALL SURFACES FOR THE FOLLOWING:

- (1) RAISED GRAIN, SPLINTERS: Sand down timber to smooth finish
- (2) NAIL/SCREW/PIN HEADS PROUD: Tap home to be flush with surface of timber
- (3) DAMAGED SCREW HEADS RESULTING IN SHARP SPLINTERS OF
- (4) METAL: Replace
- (5) SHARP ENDS OF NAILS/ SCREWS/ PINS PROTRUDING THROUGH THE PANEL: Remove and reposition
- (6) ENSURE ALL PARTS ARE SECURED AGAINST REASONABLE FORCE: Remove and refit
- (7) ENSURE THERE ARE NO LOOSE PARTS: Remove and refit/discard



IMPORTANT ! For your safety please read carefully the safety warnings

Preparation of base...

We recommend that the base onto which your building will stand should be at least 75mm larger in each direction than the total floor size of the building.

- **Actual floor area of the building:** 2156mm x 1867mm
- **Total height clearance:** 2597mm
- **Roof size:** 2637mm wide x2272mm long

The chosen position in your garden for your building should be excavated to a depth of 75mm to allow a base of sand, on to which paving slabs can be evenly laid.

You may also use an adjustable timber base or a concrete base. Whatever base you decide upon IT MUST BE LEVEL AND FIRM.

Warranty...

10 Year anti rot warranty subject to the following:

- The building must be raised so it is not in contact with any water retaining base surface (for example grass)
- This can be achieved using a timber, concrete or slab base
- When using a concrete or slab base use damp proofing strips under the bearers
- The building must have been completely treated and sealed immediately prior to or after assembly
- The building must have been re-treated and re-sealed annually

NOTE: Wood is a natural product, and therefore the following are excluded from the warranty:

- Colour change
- Warping
- Splitting.

The following are also excluded:

- Damage resulting from poor assembly
- Poor treatment application
- Poor care and maintenance
- Changes to the design
- Misuse
- General wear and tear.

Care, Maintenance and Recycling

The 5 golden rules of care:

- (1) Ensure your base is level and firm.
- (2) Ensure the building is not sitting directly on the ground using damp proof membrane or the optional timber base.
- (3) Ensure every piece of timber and surface, especially that is hidden upon assembly is treated with a top quality wood preservative at least twice (before assembly). Turn the panels upside down whilst painting so the treatment runs into the seams.
- (4) Garden buildings are not waterproof, therefore we recommend you seal between all the panels with a silicone based sealant.
- (5) Regularly check your roofing felt for weather damage and leaks.

The 6 golden rules of maintenance:

- (1) Visually check for weather damage.
- (2) Check and replace if necessary any Silicone sealant if used on your building.
- (3) Check the roofing material for wear.
- (4) The doors and windows may require periodical adjustment.
- (5) Ensure your building is well ventilated especially during hot weather.
- (6) During extremely hot periods humidify your building to prevent the timber from drying out.

Recycling and disposal:



packaging

1. Pallet and timber widely recycled
2. Cardboard widely recycled
3. Plastic strapping subject to local regulations
4. Plastic sheeting subject to local regulations.



Building

1. Timber widely recycled
2. Metal fixings widely recycled
3. Glass widely recycled
4. **Roofing felt not currently recycled.**

Stacked Parts List

FLOOR
(A3956)x02

1.078 m [3'-6"]

1.799 m [5'-11"]

PLAIN PANEL
(A3959)x03

1.810 m [5'-11"]

.990 m [3'-3"]

CORNER POST
(A3960)x06

1.800 m [5'-11"]

RAIL
(A3963)x02

.820 m [2'-8"]

.990 m [3'-3"]

HEXAGONAL CENTRE
(A3967)x01

ROOF SUPPORT
(A3966)x06

1.500 m [4'-11"]

TRIM
(A3965)x03

.150 m [6"]

.990 m [3'-3"]

ROOF
(A3968)x06

1.162 m [3'-10"]

1.091 m [3'-7"]

FINIAL
(A0111)x01

DOUBLE END SCREW
(A4029)x01

48

BLOCK
(A0091)x06

34

34

100

95x19x990
(A3964)x02


19

95


990

Hardware Chart Scale 1:1


40mm Round head nail
(A0025) x06




50mm Posi-drive screw
(A0557) x 48




60mm Posi-drive screw
(A0035) x69



80mm Posi-drive screw
(A0036) x06








In more detail.....

Before you start...


Things to check before you start:

- ✓ Ensure your base is ready – See page 4
- ✓ Check all parts as listed in the parts lists
- ✓ Read the instructions fully before starting work
- ✓ Follow all the health and safety guidelines.



















6mm

When you see the drill icon
 Only ever drill through the first piece of framework which will be a pilot hole for the screw to attach the second piece of framework
The required drill bit size is shown with the icon.



You will need:

- | | |
|--|--|
| <div style="display: flex; align-items: center; margin-bottom: 10px;">  <ul style="list-style-type: none"> • Hammer </div> <div style="display: flex; align-items: center; margin-bottom: 10px;">  <ul style="list-style-type: none"> • Spirit level </div> <div style="display: flex; align-items: center; margin-bottom: 10px;">  <ul style="list-style-type: none"> • Ladder </div> <div style="display: flex; align-items: center; margin-bottom: 10px;">  <ul style="list-style-type: none"> • 3mm 5mm drill bit </div> <div style="display: flex; align-items: center; margin-bottom: 10px;">  <ul style="list-style-type: none"> • Drill </div> <div style="display: flex; align-items: center; margin-bottom: 10px;">  <ul style="list-style-type: none"> • Tape measure & Ruler </div> <div style="display: flex; align-items: center; margin-bottom: 10px;">  <ul style="list-style-type: none"> • Sand paper </div> <div style="display: flex; align-items: center;">  <ul style="list-style-type: none"> • Pliers </div> | <div style="display: flex; align-items: center; margin-bottom: 10px;">  <ul style="list-style-type: none"> • Gloves </div> <div style="display: flex; align-items: center; margin-bottom: 10px;">  <ul style="list-style-type: none"> • Saw </div> <div style="display: flex; align-items: center; margin-bottom: 10px;">  <ul style="list-style-type: none"> • Pencil </div> <div style="display: flex; align-items: center; margin-bottom: 10px;">  <ul style="list-style-type: none"> • Goggles </div> <div style="display: flex; align-items: center; margin-bottom: 10px;">  <ul style="list-style-type: none"> • A helper for some tasks </div> <div style="display: flex; align-items: center; margin-bottom: 10px;">  <ul style="list-style-type: none"> • Screwdriver </div> <div style="display: flex; align-items: center; margin-bottom: 10px;">  <ul style="list-style-type: none"> • Sharp knife </div> <div style="display: flex; align-items: center;">  <ul style="list-style-type: none"> • Masking tape </div> |
|--|--|


Assembly instructions:

These instructions are for your safety. Please read through them thoroughly before use.
Treat all the parts before assembly – see page 5!





GB-IE

Drill 4 5mm holes through the frame work of one floor half , push the halves together and screw into place making sure both halves are inline and true.


01



Floor panel
(A3956)x02



Front



60mmScrew
(A0035)x06




GB-IE

Drill 2 holes @ 20 & 120mm from the top in one of the **Hex centre A3967** grooves so they go all the way through to the opposite groove .


In the next groove drill 2 holes @ 30 & 130mm and in the final groove 2 holes @ 40 & 140mm.

Use a pair of pliers to screw the double ended screw into the end of the **Hex centre A3967** and then screw the **Finial A0111** onto the screw.

02




Hexagonal centre
(A3967)x01




Finial
(A0111)x01



Double end screw
(A4029)x01




Make sure drill holes miss each other!!




Slot a roof support into the Hex centre slot so they are **flush at the bottom**. Fix using the holes from step 2. Repeat with another 2 roof supports using alternate slots as below. Put to one side until later.


03






Step 2
x01



Roof support
(A3966)x03



80mm Screw
(A0036)x06




Flush at the
bottom

GB-IE Drill and fix two Blocks A0091 to each Trim A3965 so they are flush with the top (longest straight side and the ends.


04




Trim (A3965)x03



Block (A0091)x06



50mmScrew (A0557)x012




GB-IE Drill 3 holes through each side of the Plain panels A3959 framework and two for the floor. The bottom of the panels have an overhang which fits flush to the floor. The widest part of the post must be on the outside. The widest part must be flush with the outside cladding. The post is 10mm shorter than the panel. Fix using the holes just drilled.


05








Plain Panel (A3959) x02



Corner Post (A3960)x01






60mmScrew (A0035)x06




GB-IE

Fix a further 2 posts using the holes drilled previously
Make sure the panels are tight to the floor and central to each side.


06



Corner Post
(A3960)x02




60mmScrew
(A0035)x06




GB-IE

Fix the final plain panel and post in the same way as before.


07



Plain Panel
(A3959) x01



Corner Post
(A3960)x01




60mmScrew
(A0035)x06




GB-IE

Drill 2 holes in each side and the bottom of the rail framework.
Align the rail framework with the edge of the floor and make sure the plain panels are central and against the floor before fixing to the posts.
The rail slats must stick past the posts by 7mm (slats thicker than the cladding).




08



Rail





60mmScrew
(A0035)x04




GB-IE The rail slats must stick past the posts by 7mm (slats thicker than the cladding).
Fix The remaining posts to the rails. Using holes drilled previously.



09



Corner Post
(A3960)x02




60mmScrew
(A0035)x04




GB-IE

Drill and 2 holes, the top one being 20mm from the top through the ends of the blocks fitted to all the trims.
Align the top of the trims with the top of the plain panels and so the trim sticks out from the post by 7mm.
Making sure all is square and true fix to the posts.





10



Trim
(A3965)x03




60mm Screw
(A0035)x12





GB-IE

Make sure all the panels are tight to the floor and central to each side and screw to the floor with 2x60mm screws per panel.
Also drill each post at an angle and screw to the floor .

11





60mm Screw
(A0035)x16




Position the step 3 assembly on top of the posts so they are in the middle of each post and the front of the notch is tight to the post.
Drill an angled hole through the post and fix with


12



Step 3
x01




60mmScrew
(A0035)x03




Place one of the **roof supports A3966** into the remaining hex slots and onto the corner post. Ensure it is flush with the bottom of the hex centre and in the middle of the post. Drill and fix to the hex centre and post with 2x 60mm screws,


13





Step 3
x01



Roof support
(A3966)x03




60mmScrew
(A0035)x06




Place all roof sections in position between each roof timber. Push firmly into place.

GB-IE Secure in position from the inside using 3 x 50mm screws in each roof framework - 6 in each roof panel




14



Roof Panel
(A3968)x06




50mmScrew
(A0557)x36




GB-IE Fit the rail cap to the rail with three 40mm nails each.



15



Rail cap
(A3964)x02



40mm Nails
(A0025)x06



Building Photographs

It will be greatly appreciated if you could forward images of your completed building to - sales@shiregb.co.uk.

20